




FRAME AND CONSOLE PARTS

For Model: DU920QWDQ3
Designer White

UNDERCOUNTER
DISHWASHER



Illus. No.	Part No.	DESCRIPTION
1	3375292	Console (Includes Item 2)
2	3374804	Insert, Console
3	3375556	Control, Electronic
4	3376359	Fuse, Thermal
5	3374778	Switch, Display
7	304231	Screw
8	3374712	Door Frame (Includes Item 27)
9	3368953	Bolt, Latch

Illus. No.	Part No.	DESCRIPTION
10	3372231	Lever, Latch
11	3369325	Switch, (2)
12	3368955	Pin, Switch (2)
13	3376441	Harness and Protector
14	3376405	Elbow, Harness
15	3400803	Screw
16	3375473	Cover Timer
17	3374501	Motor, Dual
18	3374777	Door, Sound Absorber


Illus. No.	Part No.	DESCRIPTION
19		†Panel, Front (Black/White)
20	3374011	Retainer, Panel
26	3373234	Bearing, Spring (2)
27	3374716	Channel, Retainer (Also Order Item 20)

†Refer To Dishwasher Replacement
Panel Parts List No. 675345.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INNER DOOR PARTS

For Model: DU920QWDQ3
Designer White




Illus. No.	Part No.	DESCRIPTION
1	3371481	Inner Door (Also Order Latch Door Kit 676413)
2	3376066	Latch, Detergent Dispenser
3	3369061	Snap, Detergent Dispenser
4	3369505	Actuator Assembly
5	3369506	Wet Agent, Dispenser
6	3369448	Draw Bar, Electronic
7	3374771	Clip, Console Door Retainer
8	3368999	Spring (Draw Bar)
9	3376404	Lid Assembly
10	300106	Spring, Lid
11	3372028	Pin (Lid Hinge)
12	3371710	Screen, Vent
13	3369512	Wet-Agent Cap Assembly
14	3369155	Seal (Wet-Cap)
15	3369051	Screw (9)
16	3371569	Cover, Drip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB ASSEMBLY PARTS

For Model: DU920QWDQ3
Designer White



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB ASSEMBLY PARTS


For Model: DU920QWDQ3
Designer White

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3375130	Tub Assembly	19	3369777	Thermostat	39	3374718	Clip, Grounding
2	3369078	Tub, Wheel Assembly (8)	20	301958	Clamp	40	3374765	Sound Shield
3	3368932	Runner (2)	21	3376149	Shield, Thermostat	41	3370292	Terminal Box
4	3374849	Leveler (2)	22	3374767	Insulation, Toe Panel	42	300068	Cover Assembly, Terminal Box
5	3370389	Screw, Shoulder	23	98997	Clip	43		†Access Panel (Black/White)
6	302819	Wheel (2)	25	304231	Screw		3370868	
7	343641	Screw	26	3382404	Sound Shield (2)	44	3369526	Spacer, Corrugated
8	3374719	Plate, Latch	28	3374343	Spring, Door (2)	45	3374728	Extension & Clip Assembly
9	3374720	Screw	29	3369048	Housing, Float Switch	49	3370555	Bracket, Thermostat
10	3368994	Gasket	30	3369067	Switch, Float	51	304666	Retainer, Push (2)
11	3372413	Retainer, Access Panel	31	3369049	Cover, Switch Housing	52	3368987	Support, Heater
12	3369052	Deflector (2)	32	3376397	Float & Washer Assembly	53	3371578	Screw
13	3376843	Heater	33	717488	Nut	54	3371579	Nut
14	717273	Washer, Rubber (2)	34	9742861	Toe Panel	55	3370307	Strain Relief
15	3369073	Nut (2) (Heater Terminal)	35	3369614	Panel, Access	56	3369138	Screw
16	3374621	Water Valve	36	302868	Screw			†Refer To Dishwasher Replacement Panel Parts List No. 675345.
17	304392	Screw Hi-Limit	37	3369414	Hose, Inlet			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PUMP AND MOTOR PARTS

For Model: DU920QWDQ3
Designer White



PUMP AND MOTOR PARTS

For Model: DU920QWDQ3
Designer White

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	9740982	Plate, Perforated (Includes Item 5) (Also Order Item 30) See Note A.	13	302711	Seal, Pump Outlet	26	3367197	Support, Pump Mounting (4)
2	3367173	Base, Inlet (Includes Items 1 & 5) (Also Order Item 30) See Note A.	14	3369478	Outlet, Pump (Includes Item 13)	27	3368270	Slinger (See Note A.)
3	9741232	Screw	15	3369482	Check Valve (Includes Item 6)	28	3378053	Motor & Fan Assembly (Includes Item 27) (Also Order Item 30) See Note A.
4	302710	Seal, Inlet Base	16	717000	Gasket, Pump	29	3369331	Screw
5	302709	Ball, Check	17	3376752	Pump & Motor Assembly (Includes Item 16)	30	675505	Pump Seal Kit (Includes Items 4, 12, 13 & 22)
6	95080	"O" Ring	18	302707	Bushing, Grind	31	303918	Tool, Pump Centering
7	302721	Cover, Valve	19	302718	Chopper Kit (Also Order Item 30) See Note A.	32	356138	Clamp, Hose
8	302738	Valve Stem Kit (Includes Items 12, 13 & 22) See Note A.	20	302705	Sleeve, Drain Impeller	33	3368781	Hose, Drain
9	303883	Separator Assembly (Includes Items 12, 13 & 22) See Note A.	21	9741321	Screw	34	3371748	Cap, Drain
10	3400001	Screw	22	302704	Seal, Drain Cover	35	3374757	Shaft, Absorber
11	3376402	Impeller, Wash (Includes Items 12 & 13)	23	302723	Cover, Drain (Also Order Item 30) See Note A.	36	3374756	Weight, Absorber
12	3371152	Screw & Seal,	24	303539	Impeller, Drain Kit (Also Order Item 30) See Note A.	37	3376722	Thermostat
			25	3376157	Base, Pump (Also Order Item 30) See Note A.	38	3376723	Seal, O-Ring
						39	3376358	Retainer, Thermostat


NOTE A:

Pump Centering Tool Required
For Pump Re-Assembling—
Order Item 31.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISHRACK PARTS

For Model: DU920QWDQ3
Designer White



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISHRACK PARTS


For Model: DU920QWDQ3
Designer White

Illus. No.	Part No.	DESCRIPTION
1	303722	Clip
2	3368290	Support, Arm (Also Order Items 1 & 8)
3	3368300	Spray Arm, Upper (Also Order Items 1 & 8)
4	3368006	Bumper (2)
5	300848	Tower, Pressure
6	3376961	Wheel & Transport Assembly (4)
7	3375084	Dishrack, Lower (Includes Items 4 & 6)
8	3374702	Support, Lock Spray Arm
9	3369488	Silverware Basket Assembly
10	3369485	Cover, Basket
11	3374701	Stop, Track (2)
12	3369071	Track
16	3373365	Adjuster Assy.
17	300845	End Cap
18	3375108	Dishrack, Upper
19	717528	Trim, Basket
20	300086	Handle, Basket
22	3369347	Sprayarm, Lower
23	3367910	Cap, Nozzle
24	719576	Bearing, Nozzle

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Model: DU920QWDQ3
Designer White



Illus. No.	Part No.	DESCRIPTION
1	3369816	Miscellaneous Parts Bag (Includes 2 Screws & 2 Hose Clamps)

LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

LITERATURE PARTS

LIT3369679	Instructions, Installation
LIT3367007	Instructions, Installation (Supplement) (Locating Your Water Supply)
LIT3373484	Energy Guide
LIT3373752	Guide, Use & Care
LIT3374754	Wiring Diagram
LIT3376445	Tech Sheet

Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS

LIT00677967	Do-It Yourself, Manual
-------------	------------------------

ACCESSORY PARTS

4317925	White
4317926	Avocado
4317927	Gold
4317929	Almond
4317930	Toast
4317931	Platinum

4318050	Heavy Duty
---------	------------

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH-UP (1/2oz.)

72017	White
72107	Almond
72032	Black

PAINT, PRESSURIZED SPRAY (13 oz.)

350956	Almond
285006	Superior Black
350942	Primer (White)

PAINT, TOUCH-UP (1 qt.)

978883	Almond (Uncut)
799340	Black (Uncut)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

DISHRACK REPAIR

675576	Vinyl Touch-Up (Blue)
675677	Tine Tip Repair Kit (Blue—Enough For Two Complete Dishracks)
676453	Vinyl Touch-Up (White)
675679	Tine Tip Repair Kit (White—Enough For Two Complete Dishracks)
676455	Vinyl Touch-Up (Grey)
676458	Tine Tip Repair Kit (Grey—Enough For Two Complete Dishracks)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST